


THROWBACK BIKES

ZX/Z-MIAMI

MIDFRAME MOLLE

Installation Guide

THANKS FOR PURCHASING THIS PRODUCT! PLEASE READ ALL INSTRUCTIONS BEFORE INSTALLING. IF YOU HAVE TROUBLE DON'T HESITATE TO CONTACT US AT info@throwbackbikes.com



PARTS LIST

- 1 MOLLE PANEL
- 1 LARGE L-BRACKET
- 1 SMALL L-BRACKET
- 8 M5 BOLTS
- 4 M5 NYLOC NUTS
- 8 M5 WASHERS
- 4 M5 LOCK WASHERS

TOOLS REQUIRED

- #2 PHILLIPS SCREWDRIVER
- 8MM WRENCH OR SOCKET

STEP 1. Lay the MOLLE Panel down with the logo facing upwards. Next you will attach the L-Brackets to the MOLLE Panel as shown above. Ensure the slots are in the same orientation as those on the panel (see illustration to the right). Use an M5 bolt without a washer to go through the slots in the brackets and the panel. Use a flat washer and a nut on the opposite side of the panel. Start threading the nuts on, but **DO NOT TIGHTEN YET.** 😊

Slot
alignment



Correct



Wrong



STEP 2. Move the Panel and Bracket assembly to the Mid-frame area of the bike and position as shown in the image to the left. The logo on the Panel will face the left side of the bike. Slip a lock washer and then a flat washer onto the 4 remaining bolts. Using the bolt/washer stacks align and insert the bolts through the brackets and into the threaded holes on the bike frame. Once all the bolts are started align the bracket and tighten all the hardware into the frame and through the brackets and panel.

That's it! We hope you love your new MOLLE Panel.